



MANUFACTURER'S STATEMENT

Huawei Technologies Co. Ltd
Huawei Industrial Base
Bantian, Longgang
Shenzhen 518129
People's Republic of China

Dear Customer,

About the Source of noise for SUN2000-36KTL, 60KTL-M0, 100KTL-H1 and 105KTL-H1:

When the inverter is running and produce the energy, the output AC current will pass through the inductors and establish a strong electromagnetic field around the inductors, then make the noise.

The AC current is constantly changing and the noise frequency is within the hearing range (20HZ - 20KHZ).

Please be informed that this warranty applies to the products which will make the noise level is less than 65dB. The noise will not affect the function and reliability of the product.

A handwritten signature in black ink that reads "Liming Deng".

Liming Deng
6/05/2019

Europe Solar Inverter Service Director
Solar Inverter Europe Business Development Dept